



EUREKANOL UPH (NONYLPHENOL ETHOXYLATE FREE)

COMPOSITION :

EUREKANOL UPH IS SULFITED BASED FATLIQUOR THAT IS COMPOUNDED TO GIVE MAXIMUM SOFTNESS, LIGHT WEIGHT, AND GOOD LIGHT FASTNESS. EUREKANOL UPH WOULD PRODUCE VERY SOFT, FLUFFY, SMOOTH, LIGHT, AND PLEASANT FEEL LEATHER. EUREKANOL UPH WOULD NOT CAUSE ANY FATTY SPEW DURING WINTER NOR WILL IT GIVE OFF OFFENDING SMELL. EUREKANOL UPH IS BASED ON LOW FOGGING VALUE RAW MATERIAL AND IS SUITABLE FOR AUTOMOTIVE CAR SEATS.

APPLICATION :

- A. OPENING OF WRINKLES ALONG NECK AREA OF GOATSKIN, BUFFALO, AND HEAVY BULL HIDES
- B. RETANNING, NEUTRALIZING, AND FATLIQUORING BATH
- C. UPHOLSTERY LEATHER BOTH HOUSEHOLD AND CAR SEAT
- D. NAPPA AND GARMENT LEATHER
- E. GLOVING LEATHER
- F. FLOATER LEATHER, EUREKANOL UPH WILL PRODUCE VERY GOOD PEBBLE EFFECT.

PROPERTIES :

APPEARANCE :	LIGHT BROWN VISCOUS PASTE
ANALYSIS :	pH 5.0 - 7.0
ACTIVE INGREDIENT :	50 - 52 %
STABILITY :	RETANNING, NEUTRALIZING, AND FATLIQUORING BATH.
IONIC CHARGE :	ANIONIC

PACKING : 120 KGS OR 150 KGS IN RECONDITIONED PLASTIC DRUM.



EUREKANOL UPH P-2

UPHOLSTERY LEATHER :

AFTER RECHROMING :

WASH : 200% WATER 45C 10'X3

PREFATLIQUORING : 200% WATER 45C
1/3 OF EUREKANOL UPH IN THE RECIPE AND RUN TILL COMPLETE EXHAUSTION

CHANGE FLOAT : 200% WATER 35C
ADD NEUTRALIZING AGENT
1/3 OF EUREKANOL UPH IN THE RECIPE
OTHER NEUTRALIZING CHEMICALS IN THE RECIPE
AND RUN WITH OTHER CHEMICAL

AFTER NEUTRALIZED, WASH : 200% WATER 45C 10'

NEW FLOAT : 200% WATER 45C
RETAN IN NORMAL WAY
1/3 EUREKANOL UPH AND RUN TILL EXHAUST
FORMIC ACID AS NORMAL

SPLITS VERY SHORT NAPS AND GOOD TENSILE STRENGTH :

WETTING BACK : 200% WATER 35C
3% ALCHEM CSAM RUN TILL SOFT, BEST IS TO
RUN OVER NIGHT

NEXT MORNING :

WASH : 200% WATER 35C 10'

RECHROMING : 200% WATER 35C
2% EUREKANOL 50M 20'
5% CHROME
1.5% ALTAN MS 30'
SODIUM ACETATE TILL pH 4.0 - 4.2

DRAIN AND WASH : 200% WATER 45C 10' X 3

RETANNING, DYEING, AND FATLIQUORING :
100% WATER 35C
RETANNING CHEMICALS 20'
DYESTUFF
4-5% EUREKANOL UPH
4-5% LEATHERNOL 3527M OR PU
2% AMMONIA RUN TILL DYE THROUGH
FORMIC ACID

WASH : 200% WATER 25C 10'

PASTE DRY AND CARRY ON AS USUAL